




SILO WALL MOUNTED BASIN







Section View A-A

Front View

Note: water tap hoses are not able to be concealed under basin.

Note: Dimensions are nominal measurements only

SPECIFICATIONS	
RECOMMENDED USE	Domestic
MATERIAL	Stainless Steel
CONSTRUCTION	Soundproofing Layer & 10mm Radius Corners
INSTALLATION	Wall Mounted *To be used with a basin mounted mixer
OVERFLOW	N/A
CAPACITY	5.5 Litres
WARRANTY	Structure: 10 years Finish: 5 years


Disclaimer: Products in this specification manual must by regulation be installed by licensed and registered trade people. The manufacturer/distributor reserves the right to vary specifications or delete models from their range without prior notification. Dimensions are nominal measurements only. Dimensions and set-outs listed are correct at time of publication however the manufacturer/distributor takes no responsibility for printing errors. All ABI Products are designed in Australia. Copyright ABI Interiors Pty Ltd 2021.

INSTALLATION GUIDE

This product must be installed by a licensed tradesperson


This is a general installation guide - there are many factors that are involved that can alter the installation method.

Check the desired height of basin from floor.




Drill holes into structure within walls with a wood drill bit and insert fixings. Hook basin onto square bend hooks.

Note: Wall plugs only required for masonary walls.




Secure plumbing to basin and wall outlet. Test by running water through the waste. Silicone top and sides of basin if necessary.





Fit waste and trap to basin.

Note: ensure trap can reach waste pipe.



Extend telescopic trap to reach waste pipe.

Adjust trap up or down to find desired height & cut waste to suit trap.

Note: Bottle trap & water tap hose are not able to be concealed under basin.

